

LIQUID LINE FILTER DRIER INSTALLATION PROCEDURE

P/N 34508 / 208131 / 936031,34510 / 208133 / 936033,34511 / 208134 / 936034

INSTRUCTIONS

CAUTION: REFRIGERANT MUST BE RECOVERED BEFORE ATTEMPTING INSTALLATION. SYSTEM SHOULD BE FLUSHED BEFORE STARTING.

P/N 34508 / 208131 / 936031 installs at evaporator inlet.

P/N 34510 / 208133 / 936033 installs at evaporator inlet.

P/N 34511 / 208134 / 936034 installs at condenser outlet.

1. Disconnect liquid line at appropriate location.
2. Install filter on evaporator or condenser

NOTE: These filters will add 4 inches of length to the liquid line. Use of tubing bender is required.

3. Use a tubing bender to place necessary bends in liquid line (possible in an 'S' shape) to add this extra length. Attempts to bend the liquid line without a tubing bender could cause kinking of the line. This will result in an internal restriction reducing cooling performance and ultimately damage the compressor.
4. Install liquid line on filter.