

NEW CONDENSERS WITH BUILT-IN FILTER/DRIERS

For several 2000 and newer vehicle applications, Toyota, Lexus and Honda have combined the condenser and filter/drier into one assembly. Instead of replacing the filter/drier as a separate unit, a plug in the canister (see pictures below) is unscrewed and a new desiccant kit is installed. Just like the old style filter/drier, these kits must be replaced in order to insure a long lasting repair.



TWO KITS WHICH COVER THE TOYOTA AND HONDA APPLICATIONS ARE NOW AVAILABLE:

PN 83006 Honda Odyssey (03-00)

PN 83019 Acura MDX (13-07); RI (12-05); RLX (15-14); TL (14-09); TSX (14-05); ZDX (13-10) Audi A4 Series (14-11); A5 Series (14-10); A6 Series (14-12); A7 Series (14-12); Q Series (14-11); RS5 (14-13); RS7 (14); S Series (14-13); TT Series (13-12) Cadillac ATS (14-13); CTS (14-08); SRX (09-04); STS (11-05) Chevy Camaro (14-12); Caprice (14-12); Impala (12); SS (14) Chrysler Sebring (02-01); Dodge Durango (14-11); Pickup - Fullsize / Ramcharger (14-09); Stratus (02-01); Dodge; Medium Duty Truck Dodge Medium Duty Truck (13-11); Ford Edge (14-07) Honda Accord (15-14); Civic (15-06); CR-V (15-07); CR-Z (15-11); Element (11-08); Fit (14-07); Insight (14-10); Odyssey (15-05); Pilot (15-09); Ridgeline (14-06) Jaguar S-Type (08-04); XF (15-09); XFR (14-10); XFRS (14); XK (15-07); XKR (14-07); XKRS (14-12) Jeep Grand Cherokee (14-11) Kia Borrego (09); Lexus ES350 (14-07); GS300 (07-05); GS350 (14-07); GS430 (07-06); GS460 (09-08); GX460 (14-10); GX470 (09-03); IS F (12-08); IS250 (13-06); IS350 (13-06); LS430 (06-05); LS460 (14-07); LX470 (07-05); LX570 (14-08); RX330 (06-04); RX350 (14-07); Lincoln MKX (14-07); Mazda CX-9 (12-07); Mazda 6 (07-06); MPV (06-00); RX-8 (11-04); Pontiac Vibe (10-09) Scion IQ (14-12); tC (14-05); xA (06-04); xB (14-04); xD (14-08) Subaru Legacy (14-05); Outback (14-05); Tribeca (12-06); Toyota 4Runner (14-03); Avalon (14-05); Camry (14-07); Celica (05-03); Corolla (14-05); Echo (05-03); FJ Cruiser (14-07); Highlander (14-06); Land Cruiser (14-03); Matrix (13-08); Prius (09-04); RAV4 (14-04); Sequoia (14-08); Sienna (14-04); Tundra (14-05); Venza (14-09); Yaris (14-07)

INSTRUCTIONS FOR FILTER BAG

1. Mount Drier –Bag into drier tank with overlapped area **DOWNWARD**.
2. Install plastic insert so that convex part is pointing up towards the filter bag.
3. Apply small amount of DURA SEAL 1000 or mineral oil to threads and O- rings of aluminum screw supplied.
NOTE: never use ESTER or PAG to lube threads or o rings
4. Install screw and torque to 13.0 NM(115 inch pounds)

IMPORTANT: DO NOT OVER TORQUE THE SUPPLIED NUT OR DAMAGE COULD OCCUR RESULTING IN A LEAK!